

**eDAM-8018
8-channel Thermocouple
Input Module
User's manual**

Web site: www.inlog.com.tw

Trademark:

**The names used in this manual for identification only
maybe registered trademarks of their respective companies**

Rev 1.0

Printed 2005/06//20 Taiwan

Table of Contents

| | | |
|------------------|--|-----------|
| Chapter 1 | Introduction | 7 |
| 1.1 | Overview | 7 |
| 1.2 | Module Compatibility | 7 |
| 1.3 | Communication and Programming | 7 |
| 1.4 | Software Configuration and Calibration | 7 |
| 1.5 | Watchdog Timer | 8 |
| 1.6 | Power Requirements | 8 |
| Chapter 2 | About the eDAM Analog Modules | 9 |
| 2.1 | Outline of eDAM Analog modules | 9 |
| 2.2 | Module Dimension | 10 |
| 2.3 | eDAM Analog modules | 13 |
| 2.3.1 | eDAM-8018 module | 14 |
| 2.4 | Block diagram of modules | 15 |
| 2.5 | Wire connection | 16 |
| 2.5.1 | EDAM-8018 wire connection | 16 |
| 2.6 | EDAM8018 pin assignments | 17 |
| Chapter 3 | Installation | 19 |
| 3.1 | Set up an eDAM network | 20 |
| 3.2 | Host computer | 20 |
| 3.3 | Power supply | 21 |
| 3.4 | Communication Wiring | 21 |
| 3.5 | eDAM Utility Software | 21 |
| 3.6 | eDAM Isolated RS-232/RS485 Converter | 22 |
| 3.7 | Initializing a Brand-New Module | 22 |
| 3.8 | Initialization Procedure | 23 |

| | | |
|------------------|--|-----------|
| 3.9 | Install a New eDAM to a Existing Network | 24 |
| Chapter 4 | Command Set | 25 |
| 4.1 | Introduction | 25 |
| 4.2 | Format of eDAM Commands | 26 |
| 4.3 | Response of Commands | 28 |
| 4.4 | Summary of Command Set | 29 |
| 4.4.1 | eDAM Special commands | 29 |
| 4.4.2 | Host Watchdog Command Sets | 29 |
| 4.4.3 | General Command Sets | 30 |
| 4.5 | Set brand compatible | 31 |
| 4.6 | Read current brand setting | 32 |
| 4.7 | Set Module configuration | 33 |
| 4.8 | Read analog data | 40 |
| 4.9 | Read data from channel N | 41 |
| 4.10 | Perform Span calibration | 42 |
| 4.11 | Perform Offset calibration | 43 |
| 4.12 | Read Configuration | 44 |
| 4.13 | Read CJC temperature | 45 |
| 4.14 | Enable/disable channel for multiplexing | 46 |
| 4.15 | Read channel status | 47 |
| 4.16 | Set CJC offset value | 48 |
| 4.17 | Read firmware version | 49 |
| 4.18 | Reset module | 50 |
| 4.19 | Read module name | 51 |
| 4.20 | Read CJC status | 52 |
| 4.21 | Enable/disable CJC | 53 |
| 4.22 | Host OK | 54 |
| 4.23 | Read module status | 55 |

| | | |
|---|---|-----------|
| 4.24 | Reset module status | 56 |
| 4.25 | Read host watchdog timeout value | 57 |
| 4.26 | Set host watchdog timeout value | 58 |
| 4.27 | Enable/disable calibration | 61 |
| 4.28 | Enable soft INIT function | 62 |
| 4.29 | Set module name | 63 |
| 4.30 | Set the soft INIT time out value | 64 |
| Appendix A Data Format and Input range | | 66 |
| 4.31 | Data Format of Analog Input Modules | 66 |
| 4.31.1 | Engineering Units | 66 |
| 4.31.2 | Percent of FSR (Full Scale Range) | 66 |
| 4.31.3 | Two's Complement Hexadecimal | 66 |
| Appendix B Calibration | | 69 |
| 4.32 | Calibration for eDAM8018 | 69 |
| Appendix C INIT* pin operation | | 70 |

Chapter 1 Introduction

1.1 Overview

The eDAM-8000 analog modules is a set of intelligent sensor to computer interface modules containing built-in microprocessor. They provide data comparison, and digital communication functions. Some modules provide analog I/O lines for controlling and monitoring analog signals.

1.2 Module Compatibility

The eDAM-8000 series are fully compatible to Advantech® ADAM-4000 series, ADlink® NμDAM-6000 series and ICP® I-7000 series by Command “~AA2X01V”

1.3 Communication and Programming

eDAM modules can connect to and communicate with all computers and terminals. They use RS-485 transmission standards, and communicate with ASCII format commands. All communications to and from the module are performed in ASCII, which means that eDAM modules can be programmed in virtually any high-level language.

Up to 256 eDAM modules may be connected to an RS-485 multi-drop network by using the eDAM RS-485 repeater, extending the maximum communication distance to 4,000 ft.

1.4 Software Configuration and Calibration

EDAM modules contain no pots or switches to set. By merely issuing a command from the host computer, you can change an analog input module to accept several ranges of voltage input.

Remote configuration can be done by using the command set's configuration and calibration commands. By storing configuration and calibration parameters in a nonvolatile EEPROM, modules are able to retain these parameters in case of power failure.


1.5 Watchdog Timer

A watchdog timer supervisory function will automatically reset the eDAM modules in the event of system failure. Maintenance is thus simplified.


1.6 Power Requirements




Although the modules are designed for standard industrial unregulated 24V DC power supply , they accept any power unit that supplies power within the range of +10 to +30 V DC . The power supply ripple must be limited to 5 V peak-to-peak, and the immediate ripple voltage should be maintained between +10 and +30 V DC .

2.1 Outline of eDAM Analog modules



2.2 Module Dimension





2.3 eDAM Analog modules

The eDAM provides a series of analog input or digital in/output modules to sense the analog and digital signal or to control the remote devices.

- eDAM-8018 : 8-channel Thermocouple Input Module


2.3.1 eDAM-8018 module

eDAM-8018 is a thermocouple input module with 8 input channels. Six of the eight channels are differential type and the other two are single ended type.

Specifications of eDAM-8018


- ◆ Interface: RS-485, 2 wires
- ◆ Speed (bps): 1200, 2400, 4800, 9600, 19.2K, 38.4K , 115.2K
- ◆ Analog Input type: Differential input
- ◆ Analog Channels Numbers: 8
- ◆ Analog Resolution: 16 bits
- ◆ Unit Conversion: Thermocouple, mV, V or mA
- ◆ Thermocouple Type: J, K, T, E, R, S, B, N, C
- ◆ Sampling Rate :10 Samples/Second
- ◆ Bandwidth : 15.7 Hz
- ◆ Accuracy : $\pm 0.1\%$
- ◆ Zero Drift : $0.5\mu\text{V}/^\circ\text{C}$
- ◆ Span Drift : $25\text{ppm}/^\circ\text{C}$
- ◆ CMR@50/60Hz : 150dB
- ◆ NMR@50/60Hz : 100dB
- ◆ Input Impedance : 20M Ohms
- ◆ Voltage Range: $\pm 2.5\text{V}$, $\pm 1\text{V}$, $\pm 500\text{mV}$, $\pm 100\text{mV}$, $\pm 50\text{mV}$, $\pm 15\text{mV}$
- ◆ Current Measurement: $\pm 20\text{mA}$ (with external 125W resistor)
- ◆ Power supply: +10V to +30V

2.4 Block diagram of modules



2.5 Wire connection



2.5.1 EDAM-8018 wire connection



Differential analog input for channel 0 to channel 7

Analog input mode for channel 6 can channel 7 can be selected by setting JP1 on the board

Differential input channel 6 and 7 Single-ended input channel 6 and 7



2.6 EDAM8018 pin assignments

| pin | name | description |
|-----|--------------|---|
| 1 | Vin5+ | Differential positive input channel 5 |
| 2 | Vin5- | Differential negative input channel 5 |
| 3 | Vin6+ | Differential/single-ended input channel 6 |
| 4 | Vin6-/AGND* | Differential negative ground of channel 6 or AGND for single-ended input channel 6 & 7 |
| 5 | Vin7+ | Differential/single-ended input channel 7 |
| 6 | Vin7-/INIT** | Differential negative ground of channel 7 or Initial state setting |
| 7 | DATA+ | signal, positive |
| 8 | DATA- | signal, negative |
| 9 | +VS | +10V ~ +30Vdc |
| 10 | GND | Ground |
| 11 | Vin0+ | Differential positive input channel 0 |
| 12 | Vin0- | Differential negative input channel 0 |
| 13 | Vin1+ | Differential positive input channel 1 |
| 14 | Vin1- | Differential negative input channel 1 |
| 15 | Vin2+ | Differential positive input channel 2 |
| 16 | Vin2- | Differential negative input channel 2 |
| 17 | Vin3+ | Differential positive input channel 3 |
| 18 | Vin3- | Differential negative input channel 3 |
| 19 | Vin4+ | Differential positive input channel 4 |
| 20 | Vin4- | Differential negative input channel 4 |

* Negative input of channel 6 or common AGND of channel 6 and 7 depended on JP1 setting (see page 16)

** Negative input of channel 7 or INIT (Initial state setting) pin

Chapter 3 Installation

This chapter provides guidelines to what is needed to set up and install an eDAM network. A quick hookup scheme is provided that lets you configure modules before they are installed in a network. To help you to connect eDAM modules with sensor inputs, several wiring examples are provided. Finally, you will find at the end of this chapter a programming example using the eDAM command set. Be sure to carefully plan the layout and configuration of your network before you start. Guidelines regarding layout are given in Appendix E: RS-485 Network.

NOTICE: Except for changing eDAM to other compatible modules, which have on-board switches for their baud rate setting, eDAM modules should not be opened. There is no need to open the eDAM modules: all configuration is done remotely and there are no user serviceable parts inside. Opening the cover will therefore void the warranty.

3.1 Set up an eDAM network

The following list gives an overview of what is needed to setup, install and configure an eDAM environment.

A host computer that can output ASCII characters with an RS-232C or RS-485 port.

Power supply for the eDAM modules (+10 to +30 V DC)

eDAM Series Utility software


3.2 Host computer

Any computer or terminal that can output in ASCII format over either RS-232 or RS-485 can be connected as the host computer. When only RS-232 is available, an eDAM-8520 module (RS-232/RS-485 converter) is required to transform the host signals to the correct RS-485 protocol. The converter also provides opto-isolation and transformer-based isolation to protect your equipment.

For the ease of use in industrial environments the eDAM modules are designed to accept industry standard +24 VDC unregulated power. Operation is guaranteed when using any power supply between +10 and +30 VDC. Power ripples must be limited to 5 V peak to peak while the voltage in all cases must be maintained between +10 and +30 VDC . All power supply specifications are referenced at module connector. When modules are powered remotely, the effects of line voltage drops must be considered.


3.3 Power supply

All modules use on-board switching regulators to sustain good efficiency over the 10-30V input range, therefore we can assume that the actual current draw is inversely proportional to the line voltage. The following example shows how to calculate the required current that a power supply should be able to provide.



3.4 Communication Wiring

We recommend that shielded-twisted-pair cables that comply with the EIA RS-485 standard be used with the eDAM network to reduce interference.



3.5 eDAM Utility Software

A menu-driven utility program called “DOSEDAM.EXE” for DOS or “WINEDAM.EXE for Windows is provided for eDAM module configuration, monitoring and calibration. It also includes a terminal emulation program that lets you easily communicate through the eDAM command set

3.6 eDAM Isolated RS-232/RS485 Converter

When the host computer or terminal has only a RS-232 port, an eDAM-8520 Isolated RS-232/RS-485/422 converter connected to the host’s RS-232 port is required.

This module equips a “Auto baud rate detector” inside, therefore it can detect the baud rate and data format automatically and control the direction of RS-485 precisely

3.7 Initializing a Brand-New Module

All eDAM modules in a RS-485 network must have an *unique* address ID. Therefore, to configure the brand-new 8012/D, 8014/D, 8017 before using is necessary

- ♦ Factory default settings:
 - Address ID is 01
 - Baud rate is 9600 bps, check-sum disable
 - Analog input type: Type 08 ($\pm 10V$)
 - 60Hz filter rejection mode
 - Normal operation mode (for 8012/D, 8017)
 - Six differential and 2 single-ended input mode (for 8017)
- ♦ INIT* State settings:

The eDAM I/O modules must be set at *INIT* State* when you want to change the default settings, such as the *ID address, baud rate, check-sum status* etc. All eDAM I/O modules have an special pin labeled as **INIT***. The module will be in *Default State* if the **INIT*** pin is shorted to ground when power ON. Under this state, the default configuration is set as following :

 - Address ID is 00
 - Baud rate is 9600 bps
 - Check-sum disable

Therefore, the communication between host and the module will can be easily set as the same configuration, the initialization of a module will be possible no matter what configuration is set under operating state.

3.8 Initialization Procedure

1. Power off the host computer and the installed eDAM-8520 to COM port of host computer.
2. Connect a brand new eDAM module with the RS-485. Set the module in *Default State* by shorting the **INIT*** pin to GND. Refer to Figure 4.1 for detailed wiring.
3. Power on the power supply for eDAM modules.
4. Use the **eDAM utility** to configure the address ID, baud rate, check-sum status and command sets of the module.




Figure 4.1

3.9 Install a New eDAM to a Existing Network

1. Equipments for Install a New Module
2. A existing eDAM network
3. New eDAM modules.
4. Power supply (+10 to +30 VDC)

Installing Procedures

1. Configure the new eDAM module according to the initialization procedure in section 3.7
2. The baud rate and check-sum status of the new module must be identity with the existing RS-485 network. The address ID must not be conflict with other eDAM modules on the network.
3. Power off the eDAM power supply of the existing RS-485 network.
4. Wire the power lines for the new eDAM with the existing network. Be careful about the signal polarity as wiring.
5. Wire the RS-485 data lines for the new eDAM with the existing network. Be careful about the signal polarity as wiring.
6. Wire to the input or output devices.
7. Power on the eDAM local power supply.
8. Use the eDAM utility to check entire network.

Chapter 4 Command Set

4.1 Introduction

The eDAM command is composed by numbers of characteristics, including the leading code, address ID, the variables, the optional check-sum byte, and a carriage return to indicate the end of a command.

The host computer can only command only one eDAM module except those synchronized commands with wildcard address command “#*”. The eDAM may or may not give response to the command. The host should check the response to handshake with the modules.

4.2 Format of eDAM Commands

Syntax: (Leading code)(Addr)(Command)[Data] <Cksum><CR>

Every command begins with a delimiter character. There are five valid characters: a dollar sign \$, a pound sign #, a percentage ,a wave sign '~', sign % and an at sign @.

The delimiter character is followed by a two-character address (hexadecimal) that specifies the target module. The actual two character command follows the address. Depending on the command, an optional data segment follows the command string. An optional two character checksum may be appended to the total string. Every commands is terminated by a carriage return (cr).

Conventions

| | |
|--------------|--|
| Leading Code | The first characteristic of the eDAM command, such as %,\$,#,~, @, ...etc(1- character) |
| Addr | Module's address ID, the value is in the range of 00 – FF (Hex) 2- character |
| Command | Command codes or value of variables |
| Data | Data needed by some output command |
| Checksum | Checksum in brackets indicate optional parameter, only checksum is enable then this field is required (2- character) |
| <CR> | carriage return(0x0D) |

Note:

1. all commands should be issued in ASCII uppercase characters. There is no spacing between characters.
-

Calculate Checksum:

1. Calculate ASCII sum of all characters of command (or response) string except the character return(cr)
2. Mask the sum of string with 0ffh
3. [Checksum]={ (Leading code)+(addr)+(command)+[data]} MOD 0x100

Example:

Command string : \$012(cr)

Sum of string='0'+1+2=24h+30h+31h+32h=B7h

The checksum is B7h, and [CHK]="B7"

Command string with checksum=\$012B7(cr)

Response string : !01400600(cr)

Sum of string='!'+'0'+1+'4'+0+'0'+6+'0'+0'

=21h+30h+31h+34h+30h+30h+36h+30h+30h=1ACh

The checksum is ACh, and [CHK]="AC"

Response string with checksum=!01400600AC(cr)

4.3 Response of Commands

The response message depends on eDAM command. The response is also composed with several characteristics, including leading code, variables, and carriage return for ending. There are two kinds of leading code for response message, "!" or ">" means valid command and "?" means invalid. By checking the response message, user can monitor the command is valid or invalid.

But under the following conditions, there will have no response message.

- ◆ The specified address ID is not exist.
- ◆ Syntax error.
- ◆ Communication error
- ◆ Some special commands does not have response.

4.4 Summary of Command Set

There are four categories of eDAM commands. The first is the **eDAM special commands**. The second is the **general commands**. The third is the **analog commands**., the forth is the **digital commands** and the last is **linear mapping commands**. All the commands used in the eDAM analog input module are list in the following table.

4.4.1 eDAM Special commands

| Command | Syntax | Modules | page |
|----------------------------|----------|-------------|------|
| Set brand compatible | ~AA2X01V | All modules | 31 |
| Read current brand setting | ~AA2X02 | All modules | 32 |

4.4.2 Host Watchdog Command Sets

| Command | Response | Description | Page |
|---------|-------------|----------------------------------|------|
| ~** | no response | Host OK | |
| ~AA0 | !AASS | Read Module Status | |
| ~AA1 | !AA | Reset Module Status | |
| ~AA2 | !AAVV | Read Host watchdog Timeout Value | |
| ~AA3EVV | !AA | Set Host Watchdog Timeout Value | |

4.4.3 General Command Sets

| Command | Response | Description | Page |
|-------------|-----------|----------------------------------|------|
| %AANNTTCCFF | !AA | Set Module Configuration | 33 |
| # AA | >(Data) | Read Analog Input | 40 |
| # AAN | >(Data) | Read Analog Input from channel N | 41 |
| \$ AA0 | !AA | Perform Span Calibration | 42 |
| \$ AA1 | !AA | Perform Zero Calibration | 43 |
| \$ AA2 | !AATTCCFF | Read Configuration | 44 |
| \$ AA3 | > (Data) | Read CJC Temperature | 45 |
| \$ AA5VV | !AA | Set Channel Enable | 46 |
| \$ AA6 | !AAVV | Read Channel Status | 47 |
| \$ AA9SNNNN | !AA | Set CJC Offset Value | 48 |
| \$ AAF | !AA(Data) | Read Firmware Version | 49 |
| \$ AAM | !AA(Data) | Read Module Name | 51 |
| ~AAC | !AAN | Read the CJC status | 52 |
| ~AACN | !AA | Enable/disable CJC | 53 |
| ~AAEV | !AA | Enable/Disable Calibration | 61 |
| ~AAI | !AA | Enable soft INIT function | 62 |
| ~AAO(Data) | !AA | Set Module Name | 63 |
| ~AATnn | !AA | Set soft INIT time-out value | |

4.5 Set brand compatible

| | | |
|--------------|-------------------------------|--|
| Modules: | All eDAM modules | |
| Description: | Set compatible to other brand | |
| Command: | ~AA2X01V[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 2X | eDAM exclusive code |
| | 01 | Set Compatible command. |
| | V | Brand ID 0= eDAM , 1=ADAM 2=NuDAM, 3=I-7000 |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | !AA[CHK](cr) | Valid Command |
| | ?AA[CHK](cr) | Invalid Command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | CHK | Check sum |
| | (cr) | Carriage return and then reboot module |

Note: Module will be set to default states after this command issued

Example: Set eDAM-8018 module with ID=02 to command compatible to NuDAM-6018

Command: ~022X012(cr)

Response: !02((cr)

Example: Set eDAM-8018 module with ID=02 to command compatible to I-7018

Command: ~022X013(cr)

Response: !02(cr)

4.6 Read current brand setting

| | | |
|--------------|-------------------------------|-------------------------------|
| Modules: | All eDAM modules | |
| Description: | Read current brand ID setting | |
| Command: | ~AA2X02[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 2X | eDAM exclusive code |
| | 02 | Read Brand ID com.. |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | !AAV[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | V | Brand ID |
| | CHK | Check sum |
| (cr) | Carriage return | |

Example: Read current brand ID of eDAM-8018 module with ID=02

Command: ~022X02(cr)

Response: !022((cr) // Compatible to uDAM-6018

4.7 Set Module configuration

| | | |
|--------------|--------------------------|--------------------------------------|
| Modules: | 8017,8018 | |
| Description: | Set module configuration | |
| Command: | %AANNTTCCFF[CHK](cr) | |
| Syntax: | % | Command leading code |
| | AA | Module address ID (00 to FF) |
| | NN | New eDAM address ID (00 to FF) |
| | TT | Analog input range (See *) |
| | CC | Set new baud rate of module (See **) |
| | FF | Data format (See ***) |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | !AA[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | New Module address ID |
| | CHK | Check sum |
| | (cr) | Carriage return |

*Analog Input type and range (TT)

| Type code | range | Modules |
|-----------|---------|--|
| 08 | ±10 V | 8012/D,8017,8014/D |
| 09 | ±5 V | 8012/D,8017,8014/D |
| 0A | ±1 V | 8012/D,8017,8014/D |
| 0B | ±500 mV | 8012/D,8017,8014/D |
| 0C | ±150 mV | 8012/D,8017,8014/D |
| 0D | ±20 mA | 8012/D,8017, 8014/D (Required 125Ω current conversion resistor.) |

** Baud Rate settings (CC)

| code | 03 | 04 | 05 | 06 | 07 | 08 | 09 | 0A |
|-----------|------|------|------|------|-------|-------|-------|--------|
| baud rate | 1200 | 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200 |

*** :Data format settings (FF)

| Bit | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|-----|---|---|---|---|---|---|---|---|
|-----|---|---|---|---|---|---|---|---|

Bit7: =0 for 60 Hz (default)

=1 for 50 Hz

Bit6: =1 Enable checksum

=0 Disable checksum (default setting)

Bit5: =0 for normal operation mode (Default setting)

=1 for fast operation mode (8017 only)

Bit4~bit2: No used

Bit1~bit0:=00 Engineer unit format (default setting)

=01 Percent format

=11 2's complement Hex format

Input types and data format table

| Code | Range | Format | +F.S. | zero | -F.S |
|------|----------------------------|----------------|---------|---------|---------|
| 00 | -15~+15 mV | Engineer unit | +15.000 | +00.000 | -15.000 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 8000 |
| 01 | -50~+50 mV | Engineer unit | +50.000 | +00.000 | -50.000 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 8000 |
| 02 | -100~+100 mV | Engineer unit | +100.00 | +000.00 | -100.00 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 8000 |
| 03 | -500~+500 mV | Engineer unit | +500.00 | +000.00 | -500.00 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 8000 |
| 04 | -1~+1 V | Engineer unit | +1.0000 | +0.0000 | -1.0000 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 8000 |
| 05 | -2.5~+2.5 V | Engineer unit | +2.5000 | +0.0000 | -2.5000 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 8000 |
| 06 | -20~+20 mA | Engineer unit | +20.000 | +00.000 | -20.000 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 8000 |
| OE | Type J T/C -210~760 °C | Engineer unit | +760.00 | +00.000 | -210.00 |
| | | % of F.S.R | +100.00 | +000.00 | -027.63 |
| | | 2's complement | 7FFF | 0000 | DCA2 |
| 0F | Type K T/C -270~1372 °C | Engineer unit | +1372.0 | +00.000 | -0270.0 |
| | | % of F.S.R | +100.00 | +000.00 | -019.68 |
| | | 2's complement | 7FFF | 0000 | E6D0 |

| Code | Range | Format | +F.S. | zero | -F.S |
|------|----------------------------|----------------|---------|---------|---------|
| 10 | Type T T/C -270~400 °C | Engineer unit | +400.00 | +00.000 | -270.00 |
| | | % of F.S.R | +100.00 | +000.00 | -067.50 |
| | | 2's complement | 7FFF | 0000 | DCA2 |
| 11 | Type E T/C -270~1000 °C | Engineer unit | +1000.0 | +0000.0 | -0270.0 |
| | | % of F.S.R | +100.00 | +000.00 | -027.00 |
| | | 2's complement | 7FFF | 0000 | DD71 |
| 12 | Type R T/C 0~1768 °C | Engineer unit | +1768.0 | +00.000 | -0000.0 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 0000 |
| 13 | Type S T/C 0~1768 °C | Engineer unit | +1768.0 | +00.000 | -0000.0 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 0000 |
| 14 | Type B T/C 0~1820 °C | Engineer unit | +1820.0 | +00.000 | -0000.0 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 0000 |
| 15 | Type N T/C -270~1300 °C | Engineer unit | +1300.0 | +0000.0 | -0270.0 |
| | | % of F.S.R | +100.00 | +000.00 | -020.77 |
| | | 2's complement | 7FFF | 0000 | E56B |
| 16 | Type C T/C -270~2320 °C | Engineer unit | +2320.0 | +0000.0 | -0000.0 |
| | | % of F.S.R | +100.00 | +000.00 | -100.00 |
| | | 2's complement | 7FFF | 0000 | 0000 |

Note:

It's needed to short the INIT* pin to ground while changing baud rate and/or enable/disable checksum (see following examples) or using " ~AAI" soft INIT command to change baud rate and/or checksum without shorting INIT* pin to ground (see)

Example 1: Change ID address from 01 to 03 (Assume current baud rate is 9600 and checksum disabled)

Command: %0103080600(cr)

Response: !03(cr)

response new module ID address 03 (change ID address only)

Example 2: Change baud rate from 9600 to 19200(Assume current ID is 03, baud rate is 9600, and checksum disabled).

Because that the baud rate is changed from 9600 to 19200, the following procedures should be done before sending this command

1. Power off the module
2. Short INIT* pin to GROUND (see Appendix C)
3. Power on the module
4. send command string
5. Command: %0003080700(cr)
6. Response: !03(cr)
7. response module ID address 03
8. Power off module
9. Open INIT* pin and power on module again

Example 3: Enable checksum(Assume current ID is 03, baud rate is 9600 and checksum disabled).

Because that the checksum is changed from disable to enable, the following procedures should be done before sending this command

1. Power off the module
2. Short INIT* pin to GROUND (see Appendix C)
3. Power on the module
4. send command string
5. Command: %0003080640(cr)
6. Response: !03(cr)
7. response module ID address 03
8. Power off module
9. Open INIT* pin and power on module again (checksum enabled)

Example 4: Change baud rate from 9600 to 19200 and enable checksum (Assume current ID is 03, baud rate is 9600 and checksum disabled).

Because that both the baud rate and checksum is changed , the following procedures should be done before sending this command

1. Power off the module
2. Short INIT* pin to GROUND (see Appendix C)
3. Power on the module
4. send command string
5. Command: %0003080740(cr)
6. Response: !03(cr)
7. response module ID address 03
8. Power off module
9. Open INIT* pin and power on module again (Baud rate changed to 19200 and checksum enabled)

It is recommended to use the setup utility to configure the module (see section 3.7 and 3.8)

Related topics: \$AA2

4.8 Read analog data

| | | |
|-------------------------|-----------------------------|-------------------------------|
| Modules: | For,8017,8018 | |
| Description: | Read the ANALOG input value | |
| Command: | #AA[CHK](cr) | |
| Syntax: | # | Command leading code |
| | AA | Module address ID (00 to FF) |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | >(data)[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | > | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | (data) | Analog input data(see *) |
| | CHK | Check sum |
| | (cr) | Carriage return |

If analog data of eDAM-8018 module be read by using this command, data of all channels are responded as follows:

>(chan.0 data) (chan.1 data) (chan.7 data) [CHK](cr)

Example 5: Read analog input data from eDAM8018 at addr.=05

Command: #05(cr)

Response:

+02.645-01.001+03.023+00.321+08.123-03.333+09.210-06.000(cr)

Related command: \$AA4

4.9 Read data from channel N

| | | |
|-------------------------|---|--|
| Modules: | For 8017,8018 | |
| Description: | Read the analog input value of a specified AD channel from an analog input module | |
| Command: | #AAN[CHK](cr) | |
| Syntax: | # | Command leading code |
| | AA | Module address ID (00 to FF) |
| | N | Command for reading analog input value |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | >(data)[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | > | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | (data) | Analog input data |
| | CHK | Check sum |
| | (cr) | Carriage return |

Example 6: Read the analog input channel 1 of AD module at address 06 in the network. (Data format is engineering unit)

User command: #061<CR>

Response: >+1.6888<CR>

Related command: \$AA

4.10 Perform Span calibration

| | | |
|-------------------------|---|-------------------------------|
| Modules: | For 88017,8018 | |
| Description: | To correct the gain errors of AD converter by using the span calibration. | |
| Command: | \$AA0[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 0 | Command for span calibration |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | !AA[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID (00 to FF) |
| | CHK | Check sum |
| | (cr) | Carriage return |

Note: To perform the calibration, a proper input signal should be connected to the analog input module. Different input range have different input voltage, detail refer Appendix B “**Calibration**”.

Example 7: Perform span calibration of module with address=06

Command: \$060<CR>

Response: !06<CR>

4.11 Perform Offset calibration

| | | |
|-------------------------|--|--------------------------------|
| Modules: | For 8017,8018 | |
| Description: | To correct the offset errors of AD converter by using the offset calibration | |
| Command: | \$AA1[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 1 | Command for offset calibration |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | !AA[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID (00 to FF) |
| | CHK | Check sum |
| | (cr) | Carriage return |

Note:

To perform the calibration, a proper input signal should be connected to the analog input module. Different input range have different input voltage, detail refer Appendix B “**Calibration**”.

Example 8: Perform offset calibration of module with address=06

Command: \$061<CR>

Response: !06<CR>

4.12 Read Configuration

| | | |
|--------------|---------------------------|---|
| Modules: | For eDAM modules | |
| Description: | Read module configuration | |
| Command: | \$AA2[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 2 | Command for reading configuration |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | !AATCCFF[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | TT | Analog input type and range (see sec.4.7) |
| | CC | Baud rate (see sec.4.7) |
| | FF | Data format of module (see sec.4.7) |
| | CHK | Check sum |
| | (cr) | Carriage return |

Example 9: Read configuration of module with ID address=05

Command: \$052(cr)

Response: !05080600(cr)

Read address ID=05 module configuration

08=Analog input range ± 10 V

06=9600 baud rate

00=no checksum,

Related command: \$AA2

4.13 Read CJC temperature

| | | |
|-------------------------|-----------------------|--|
| Modules: | For 8018 only | |
| Description: | Read CJC temperature. | |
| Command: | \$AA3[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 3 | Command for reading CJC temp. |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | >AA(data) [CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | > | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | data | CJC temperature in degree Celsius, including a sign byte, '+' or '-', and followed by 5 decimal digital with fixed decimal point in tenths of a degree |
| | CHK | Check sum |
| (cr) | Carriage return | |

Example 10: Read CJC temperature at address ID=03

Command: \$013<cr>

Response: >+0028.5<cr> CJC temperature is +28.5°C

Related command: \$AA9SNNNN

4.14 Enable/disable channel for multiplexing

| | | |
|--------------|--|---|
| Modules: | For 8017,8018 | |
| Description: | Enable/Disable multiplexing simultaneously for individual channel. | |
| Command: | \$AA5VV[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 5 | Command for reading digital I/O status |
| | VV | bit 3~0 of 1st character control channel 7-4 bit 3~0 of 2nd character control channel 3-0 bit value 0: Disable channel bit value 1: Enable channel |
| | CHK | Check sum |
| | (cr) | Carriage return |
| | Response: (see Note) | !AA[CHK](cr) |
| ?AA[CHK](cr) | | Invalid command |
| ! | | Delimiter for valid command |
| ? | | Delimiter for invalid command |
| AA | | Module address ID (00 to FF) |
| CHK | | Check sum |
| (cr) | | Carriage return |

Example 1: Enable channel 3 and channel 6, the other channels are all disable of eDAM-8018.

Command: \$06548<cr>

'48' is 01001000 that means enable channel 3 and channel 6, the other channels are all disable.

Response: !06<cr>

Related command:

4.15 Read channel status

| | | |
|-------------------------|--|------------------------------------|
| Modules: | For eDAM 8017 only | |
| Description: | Read the enable/disable status the channels of eDAM-8017 | |
| Command: | \$AA6[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 6 | Command for reading channel status |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | !AAVV[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID (00 to FF) |
| | VV | Channel status (See sec 4.14) |
| | CHK | Check sum |
| (cr) | Carriage return | |

Example 1: Read channel status of eDAM-8017 with address=06.

Command: \$066<CR>

Response: !0648<CR>

4 is equals binary 0100 that means enable channel 6 and disable channel 7, 5, 4.

8 is equals binary 1000 that means enable channel 3 and disable channel 2, 1, 0.

Related command:

4.16 Set CJC offset value

| | | |
|--------------|---------------------------------------|--|
| Modules: | For eDAM 8018 only | |
| Description: | Set Cold junction offset of eDAM-8018 | |
| Command: | \$AA9SNNNN[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 9 | Command for setting CJC offset value |
| | SNNNN | CJC offset value including a sign and 4 hexadecimal digits from -1000 to +1000, each count is 0.01°C |
| | CHK | Check sum |
| | (cr) | Carriage return |
| | Response: (see Note) | !AA[CHK](cr) |
| ?AA[CHK](cr) | | Invalid command |
| ! | | Delimiter for valid command |
| ? | | Delimiter for invalid command |
| AA | | Module address ID (00 to FF) |
| CHK | | Check sum |
| (cr) | | Carriage return |

Example 1: Set Address 01 CJC offset to increase 16 counts(+0.16 °C).

Command: \$019+0010<CR>

Response: !01<CR>

Related command: \$AA3

4.17 Read firmware version

| | | |
|-------------------------|---------------------------------|---------------------------------------|
| Modules: | For eDAM DIO modules | |
| Description: | Read module's firmware version. | |
| Command: | \$AAF[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | F | Command for reading firmware version. |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | !AA(data)[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | data | Module's firmware version. |
| | CHK | Check sum |
| (cr) | Carriage return | |

Example 2: Read firmware version of module address ID=30

Command: \$30F<CR>

Response: !30A1.04<CR>

! Command is valid., Address ID=30, Firmware
Version=A1.04

4.18 Reset module

| | | |
|--------------|---------------------------------|------------------------------|
| Modules: | All eDAM modules | |
| Description: | Reset all existing eDAM modules | |
| Command: | \$AARS[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | RS | Reset command |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | No response | |

Note: Reset command will reset module to default settings.

This command has no response from module

Example 3: Example: Reset module with ID address is 02

Command: \$02RS(cr)

Response: No response

Related command: \$AAM

4.19 Read module name

| | | |
|-------------------------|----------------------|-----------------------------------|
| Modules: | For eDAM DIO modules | |
| Description: | Read module's name | |
| Command: | \$AAM[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | M | Command for reading module's name |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | !AA[data][CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | data | Module's name |
| | CHK | Check sum |
| | (cr) | Carriage return |

Example 4: Read module's name of address ID=30

Command: \$30M<CR>

Response: !308014<CR>

! Command is valid., Address ID=30, module's name=8014

Related command: \$AARS

4.20 Read CJC status

| | | |
|--------------|--|-----------------------------------|
| Modules: | For eDAM 8018 only | |
| Description: | Read Cold junction status of eDAM-8018 | |
| Command: | ~AAC[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | C | Command for reading CJC status |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | !AAN[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID (00 to FF) |
| | N | 0: CJC disabled 1: CJC enabled |
| | CHK | Check sum |
| | (cr) | Carriage return |

Example 1: Read Address 01 CJC status and response CJC enabled

Command: ~01C<CR>

Response: !011<CR>

Related command: ~AACN

4.21 Enable/disable CJC

| | | |
|--------------|---|---------------------------------|
| Modules: | For eDAM 8018 only | |
| Description: | Enable/disable Cold junction of eDAM-8018 | |
| Command: | ~AACN[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | C | Command for reading CJC status |
| | N | 0: disable CJC 1: enable CJC |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | !AA[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID (00 to FF) |
| | (cr) | Carriage return |

Example 1: Enable Address 01 CJC

Command: ~01C1<CR>

Response: !01<CR>

Related command: ~AAC

4.22 Host OK

| | | |
|--------------|--|----------------------|
| Modules: | For all eDAM modules | |
| Description: | Host send this command to all modules for send the information "Host OK" | |
| Command: | ~**[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | ** | For all modules |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | No response | |

Note:

When host watchdog timer is enable, host computer must send this command to all module before timeout otherwise "**Host watchdog timer enabled**" module's output value will go to safety state output value.

4.23 Read module status

| | | |
|--------------|------------------------------|--|
| Modules: | For all eDAM modules | |
| Description: | Read watchdog timeout status | |
| Command: | ~AA0[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 0 | Command for reading timeout status |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | ! AASS[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | SS | SS=00 - watchdog timeout is cleared SS=04 - watchdog timeout is set |
| | CHK | Check sum |
| | (cr) | Carriage return |

Note:

1. the watchdog timeout status will be stored in EEPROM of the module and can only be cleared by issuing ~AA1 command (see ~AA1 and ~AA3EVV commands)
2. When the module's watchdog timeout value is reached, this command will be responded with SS=04 otherwise SS=00

Example:

Command: ~010<cr> Response: !0104

The host watchdog timeout status is set

4.24 Reset module status

| | | |
|--------------|-------------------------------|---|
| Modules: | For all eDAM modules | |
| Description: | Reset watchdog timeout status | |
| Command: | ~AA1[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 1 | Command for resetting watchdog timeout status |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | ! AA [CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | CHK | Check sum |
| | (cr) | Carriage return |

Note:

1. The module's watch dog status will be cleared after this command issued
2. (reference to ~AA3EVV command)

4.25 Read host watchdog timeout value

| | | |
|--------------|----------------------------------|--|
| Modules: | For all eDAM modules | |
| Description: | Read host watchdog timeout value | |
| Command: | ~AA2[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 2 | Command for reading watchdog timeout value |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | !AAEVV[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | E | Host watchdog enable/disable status E=1 – Enabled E=0 – Disabled |
| | VV | Timeout value in Hex format from 01 to FF=25.5 seconds (one unit is 0.1 sec) |
| | CHK | Check sum |
| | (cr) | Carriage return |

(also see sec 4.26)

4.26 Set host watchdog timeout value

| | | |
|--------------|---------------------------------|--|
| Modules: | For all eDAM modules | |
| Description: | Set host watchdog timeout value | |
| Command: | ~AA3EVV[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | 3 | Command for setting watchdog timeout value |
| | E | 1= enable, 0= disable Host watchdog |
| | VV | Timeout value (01~FF, each for 0.1 second) |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: | !AA[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | CHK | Check sum |
| | (cr) | Carriage return |

Note:

If host watchdog timer is enabled, the host should send *Host OK* (see section 4.22) command periodically within Timeout value to refresh the timer, otherwise the module will be forced to safety state

Set module (ID=04) to have watchdog timeout value 10.0 seconds and enable host watchdog

Command: ~043164<cr>

Set watchdog timeout value 10.0 sec and enable host watchdog

Response: !04<cr> Valid command

Example 2: Read watchdog timeout value form module (ID=04)

Command: ~042<cr>

Read watchdog timeout value

Response: !04164

Watchdog timeout value=10.0 seconds, and host watchdog is enabled

Example 3: Reset watchdog timer

Command: ~**<cr>

Read host watchdog timer

Stop sending any command string to modules for at least 10.0 seconds. The LED on the module will go to flash. The flash LED indicates the host watchdog is timeout and timeout status is set

Example 4: Read watchdog timeout status

Command: ~040<cr>

Read module (ID=04) watchdog timeout status

Response: !0404<cr>

Timeout status is set

Example 5: Read watchdog timeout value form module (ID=04)

Command: ~042<cr>

Read watchdog timeout value

Response: !04164

Watchdog timeout value=10.0 seconds, and host watchdog is **enabled**

Example 6: Reset watchdog timeout status

Command: ~041<cr>

Reset watchdog timeout status

Response: !04<cr>

Watchdog timeout is cleared and LED stop flashing, and host watchdog is disabled

Example 7: Read watchdog timeout status

Command: ~040<cr>

Read module (ID=04) watchdog timeout status

Response: !0400<cr>

Timeout status is cleared

4.27 Enable/disable calibration

| | | |
|-------------------------|-------------------------------------|---|
| Modules: | For 8012,8012D,8014,8014D,8017 | |
| Description: | Enable or disable Span calibration. | |
| Command: | ~AAEV[CHK](cr) | |
| Syntax: | ! | Command leading code |
| | AA | Module address ID (00 to FF) |
| | E | Enable/disable calibration command |
| | V | 0=Disable span calibration 1=Enable span calibration |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | !AA[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID (00 to FF) |
| | CHK | Check sum |
| | (cr) | Carriage return |

Note: send enable calibration command before performing the calibration,

Example 8: Perform span calibration of module with address=06

Command: \$06E1<CR> // Enable calibration

Response: !06<CR>

Command: \$060<CR> // perform span calibration

Response: !06<CR>

4.28 Enable soft INIT function

| | | |
|-------------------------|---------------------------|-------------------------------|
| Modules: | For 8018 only | |
| Description: | Enable soft INIT function | |
| Command: | ~AAI[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | I | Enable soft INIT function |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | !AA[CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | CHK | Check sum |
| (cr) | Carriage return | |

Note:

This command is used to enable modification of Baud Rate and Check Sum settings without shorting INIT pin

Example 9: Enable Address 06 software INIT function

Command: ~06I<CR> // Enable software INIT function

Response: !06<CR>

Related command: ~AATnn and %AANNTTCCFF

4.29 Set module name

| | | |
|-------------------------|----------------------|--------------------------------|
| Modules: | For all eDAM modules | |
| Description: | Set new module name. | |
| Command: | ~AAO(data)[CHK](cr) | |
| Syntax: | \$ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | O | Command for setting new name |
| | (data) | Module name, Max. 6 characters |
| | CHK | Check sum |
| | (cr) | Carriage return |
| Response: (see Note) | !AA [CHK](cr) | Valid command |
| | ?AA[CHK](cr) | Invalid command |
| | ! | Delimiter for valid command |
| | ? | Delimiter for invalid command |
| | AA | Module address ID |
| | CHK | Check sum |
| | (cr) | Carriage return |

Example 10: Set new module name at address ID=30

Command: ~30O4012<CR>

Set new name 4012 to the module at address ID=30

Response: !30<CR>

! Command is valid.,

Related command:

4.30 Set the soft INIT time out value

| | | |
|--------------|----------------------------------|--|
| Modules: | For 8018 only | |
| Description: | Set the soft INIT time out value | |
| Command: | ~AATnn[CHK](cr) | |
| Syntax: | ~ | Command leading code |
| | AA | Module address ID (00 to FF) |
| | T | Enable soft INIT function |
| | nn | nn= Two hexadecimal digits representing time out value in seconds. The max. time out value is 60 seconds |
| | CHK | Check sum |
| | (cr) | Carriage return |
| | Response: (see Note) | !AA[CHK](cr) |
| ?AA[CHK](cr) | | Invalid command |
| ! | | Delimiter for valid command |
| ? | | Delimiter for invalid command |
| CHK | | Check sum |
| (cr) | | Carriage return |

Note:

When changing Baud Rate and/or Checksum without altering INIT* pin, ~AAI,%AANNTTCCFF commands should be sent consecutively and the time interval between two commands should be less than soft INIT time out value.

If soft INIT time out valu=0, then the Baud rate and/or checksum can not be changed by using ~AAI,%AANNTTCCFF soft commands.

The power on default value = 0 seconds

Example 1: Enable Address 06 software INIT* function

```
Command: ~06I<CR>           // Enable software INIT* function
Response: !06<CR>
Command: ~0606000700<CR> // change baud rate
Response: ?06<CR>           // attempts to change Baud
                             // rate/without first altering INIT*
                             // pin or the soft INIT time out
                             // value=0
```

Example 2: Enable Address 06 software INIT* function

```
Command: ~06T10<CR>         // soft INIT* time out value=10
                             // seconds
Response: !06<CR>
Command: ~06I<CR>           // Enable software INIT* function
Response: !06<CR>
Command: ~0606000700<CR> //change baud rate
Response: !06<CR>           // Baud rate changed successfully
```

Related command: ~AATnn and %AANNTTCCFF

Appendix A Data Format and Input range

4.31 Data Format of Analog Input Modules

There are three types of data format used in analog input modules.

1. Engineering units.
2. Percent of FSR (Full Scale Range).
3. Two's complements hexadecimal.

4.31.1 Engineering Units

Example 3: Input Range is ± 5 V
Input is -1.37 Volts
engineering units: **-1.3700**<CR>

Example 4: Input Range is ± 10 V
Input is +3.653 Volts
engineering units: **+03.653**<CR>

4.31.2 Percent of FSR (Full Scale Range)

Example 5: Input Range is ± 5 V
Input is +1 Volts
% of FSR: **+020.00**<CR> $(+(20/100) \times 5 \text{ V}) = +1 \text{ V}$

Example 6: Input Range is ± 10 V
Input is +4 Volts
% of FSR: **+040.00**<CR> $(+(40/100) \times 10 \text{ V}) = +4 \text{ V}$

4.31.3 Two's Complement Hexadecimal

Example 7: Input Range is ± 5 V
Input is +1 Volts
Two's complement hexadecimal: **1999**<CR>
 $((1/5) \times 32768) = 6553.6 = 1999\text{H}$

Example 8: Input Range is ± 5 V

Input is -2 Volts

Two's complement hexadecimal: CD27<CR>

$$\left(\frac{-2}{5}\right) \times 32768 = -13107.2 = \text{CD27H}$$

Example 9: Input Range is ± 10 V

Input is +4 Volt

Two's complement hexadecimal: 3333<CR>

$$\left(\frac{4}{10}\right) \times 32768 = 13107.2 = \text{3333H}$$

Appendix B Calibration

4.32 Calibration for eDAM8018

The offset calibration is used to calibrate output offset when the input voltage is 0V

The span calibration is used to calibrate the full scale output when the input is full scale voltage

- ◆ Calibration procedures
 1. Apply zero voltage to channel 0 of analog module (refer to sec 2.5)
 2. Issues configuration command with type=08 (refer to sec 4.7)
 3. Issues enable calibration command
 4. Issues zero offset calibration command five times
 5. Apply span voltage to channel 0 of analog module
 6. Issues span calibration command five times
 7. Repeat procedure 1 to procedure 6 two times

| Type code | 08 | 09 | 0A | 0B | 0C | 0D |
|------------|------|-----|-----|--------|--------|-------|
| Zero input | 0V | 0V | 0V | 0mV | 0mV | 0mA |
| Span input | +10V | +5V | +1V | +500mV | +150mV | +20mA |

Table 7-1: 8012/D,8014/D,8017 Calibration voltages

Note:

While using calibration type 0D to calibrate 8012/D, 8017 module, an external shunt resistor 125 ohms should be connected to channel 0 of module

Appendix C INIT* pin operation

The “INIT* mode” has two purposes, one for reading module current configuration, and another for configuring the module baud rate and checksum

■ Reading module current configuration

Each eDAM module has a built-in EEPROM which is used to store the configuration information such as address ID, type, baud rate etc..

If the user unfortunately forget the configuration of the module. User may use a special mode called “INIT* mode” to resolve the problem. When the module is set to “INIT*” mode”, the default settings are ID=00, baud rate=9600, and checksum = disable

The following steps show you how to enable INIT* mode and read the current configuration

Power off the module

Connect the “INIT*” pin to GND pin

Power on the module

Send command \$002<cr> in 9600 baud rate to read the current configuration stored in the EEPROM

Power off the module again

Open “INIT*” pin to force the module to normal mode



Configuring the module baud rate and checksum

The module should be set to "INIT* mode", While changing baud rate and/or checksum state by sending "Set module configuration" command (see section 4.7)

The following steps show you how to enable INIT* mode and change baud rate and/or checksum state

Power off the module

Connect the "INIT*" pin to GND pin

Power on the module

Send command %AANNTTCCFF in 9600 baud rate to set baud rate and/or checksum state (*ID should be set to 00 in "INIT* mode"*)

Power off the module again

Open "INIT*" pin to force the module to normal mode